

## 03-35 T158, Sensor de temperatura


### Momento de aperto - T158

---

**Componente**

**Momento de  
aperto**

Sensor de temperatura dos gases de escape



30 Nm

---